

**At which supply voltage begins the 0-10 V signal output of the transmitters to work safely?**

Usually at 13 VDC.