

How is the load change defined for pressure switches / pressure transducers?

The load change is defined via

- the rate of the pressure rise
- the frequency and
- the pressure curve